






# Danforth

## **KEILHAUER**

1450 Birchmount Road, Toronto, Ontario, Canada M1P 2E3  
tel 416 759 5665 fax 416 759 5723 1 800 724 5665  
[www.keilhauer.com](http://www.keilhauer.com) [info@keilhauer.com](mailto:info@keilhauer.com)



## 5. Back Height Adjustment (Task chair only)




**Use** the sides of the back just above the seat and grab with both hands

**To raise** lift the back up and towards you – you will hear a click for each different height

**To lower** lift the back to the highest setting and it will disengage allowing it to drop down to the starting (lowest) height; the back must return to the starting position to reengage the height adjustment mechanism

## 2. Tilt




**Use** the big round knob under the front of the seat

**To increase** tension turn the knob clockwise

**To decrease** tension turn the knob counter-clockwise



### 3. Tilt Lock



**Use** the paddle shaped lever on the left side underneath the seat


**To unlock tilt** pull the front of the lever up and tilt back slightly

**To lock tilt** recline to your desired position and push the front of the lever down

**Optional forward tilt** while the back tilt is unlocked, using the small knob lever at the front right side underneath the seat, push the knob in to “in” gage forward tilt – pull the knob out to lock “out” forward tilt (the chair must be reclined slightly each time to reset this feature)



## 4. Arm Height Adjustment




**Use** the round button under the front edge of the arm

**To raise or lower** push the button in and raise or lower the arm rest and release button to lock



## 1. Seat Height Adjustment



**Use** the paddle shaped lever on the right side underneath the seat

**To raise** lift your weight off the seat while lifting the front of the lever

**To lower** sit on the seat while lifting the front of the lever